


How to set up the 3 button navigation menu on the Syco RS-441

Go to "settings"



Go to "Systemnavigation"



Select "Navigation with 3 buttons"

